



MAINTENANCE NOTES:

- 1) INITIAL SETUP OF BYPASS PUMPING SHOULD BE COMPLETED DURING TIME WHEN 3-4 DAYS OF DRY WEATHER IS FORECASTED.
- 2) INSPECT STREAM DIVERSION DAILY. CORRECT ANY DEFICIENCIES IMMEDIATELY.
- 3) AREAS ADJACENT TO WORK AREA SHOULD BE STABILIZED.

NOTES:

- 1. CONSTRUCTION SEQUENCE FOR STREAM DIVERSION MUST BE FOLLOWED.
- 2. BE SURE TO ANCHOR ALL PUMPS AND PIPES SECURELY.
- 3. PERIODICALLY CHECK PUMP FOR ADEQUATE FUEL SUPPLY AND REMOVE ANY BLOCKAGES THAT MAY OCCUR.
- 4. BE SURE TO HAVE AN EXTRA PUMP AND AN EXTRA SILT BAG ON SITE IN CASE OF FAILURES.
- 5. SILT BAG MUST BE USED IN DEWATERING OPERATION. SEE SILT BAG DETAIL FOR USE WITH PUMP.
- 6. DISCHARGE FROM SILT BAG SHOULD NOT CAUSE EROSION.

DETAIL NUMBER
2018-024
SHEET 1 of 1

STREAM DIVERSION - BYPASS PUMPING