



**MAINTENANCE NOTES:**  
 1) INITIAL CONSTRUCTION OF DIVERSION CHANNEL SHOULD BE COMPLETED DURING TIME WHEN 3-4 DAYS OF DRY WEATHER IS FORECASTED.  
 2) INSPECT STREAM DIVERSION DAILY. CORRECT ANY DEFICIENCIES IMMEDIATELY.  
 3) AREAS ADJACENT TO WORK AREA SHOULD BE STABILIZED.

**NOTES:**

1. CONSTRUCTION SEQUENCE FOR STREAM DIVERSION MUST BE FOLLOWED.
2. BE SURE TO ANCHOR ALL PUMPS AND PIPES SECURELY.
3. PERIODICALLY CHECK PUMP FOR ADEQUATE FUEL SUPPLY AND REMOVE ANY BLOCKAGES THAT MAY OCCUR.
4. BE SURE TO HAVE AN EXTRA PUMP AND AN EXTRA SILT BAG ON SITE IN CASE OF FAILURES.
5. SILT BAG MUST BE USED IN DEWATERING OPERATION. SEE SILT BAG DETAIL FOR USE WITH PUMP.
6. DISCHARGE FROM SILT BAG SHOULD NOT CAUSE EROSION.



# STREAM DIVERSION - FABRIC LINED